

#### 4. USING THE CONTROLS

**Microphone Mute:** To mute your voice so the caller cannot hear you, press the switch down on the MUTE side. To unmute, press down on TALK side of the switch.



**Volume Control:** To increase volume in your earpiece, roll the wheel in the direction of the wider lines. To decrease volume roll the wheel in the direction of the narrower lines.



**Answer/End Button:** To answer or end a call without touching your handset, press and release the button on the back of the inline control. This feature does not work with some phones, including Motorola.



Rear view of control

#### VXI LIMITED WARRANTY

1. VXI warrants that your CP110 headset will be free from defects in material and workmanship for one year from the date of purchase. If, during the first year from the date of purchase, your CP110 headset fails to work due to a defect in material or workmanship, VXI will repair or replace the product, at its election, free of charge. Without proof of purchase, the warranty period begins on the date of manufacture.

2. The foregoing limited warranty does not cover equipment failure attributable to accident, improper operation, misuse, abuse, or any cause other than defects in the materials or workmanship of VXI's products.

3. VXI's obligations under this warranty are limited to repair or replacement (at our option) of any defective part returned to VXI, freight prepaid. Returned products require a Return Authorization that may be obtained by calling customer service at 1-800-742-8588.

4. THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not permit the exclusion of implied warranties and the foregoing exclusions may not apply to you.

5. In no event shall VXI be responsible for any other damages whatsoever, including direct, indirect, special, incidental, consequential, or other damages for breach of this or any other warranty, express or implied.

6. Products returned to VXI for in-warranty, freight prepaid and with proper Return Authorization, will be return shipped to the customer at VXI's expense.

**VXI CORPORATION** One Front Street, Rollinsford, NH 03869  
603-742-2888 Toll Free 800-742-8588 [www.blueparrott.com](http://www.blueparrott.com) PN202345B

© 2007 VXI Corporation

**blueparrott** CP110 HEADSET



For cellular or cordless phones

## Using the Headset


### 1. CONNECT THE HEADSET TO YOUR PHONE

For cordless or mobile phones with a 3-pin 2.5mm headset jack. If you do not know if your phone has a 3-pin headset jack, consult the handset user guide or contact the headset manufacturer.

Insert the 2.5mm plug directly into the headset jack on the phone. For mobile phones requiring an adapter, insert the 2.5mm plug into the headset jack on the adapter.


*Not compatible with Nokia® phones.*

*For additional headset compatibility information please visit our website at [www.blueparrott.com](http://www.blueparrott.com)*




### 2. CHOOSE A SIDE FOR THE MICROPHONE

Determine which side of your head you would prefer to locate the microphone. Swivel the microphone boom up and over to the other side as shown.



### 3. MICROPHONE ADJUSTMENT

Position the microphone so it is located one finger-width from the corner of your mouth just below your bottom lip. The microphone has the word TALK or a painted dot printed on it (under the cushion). Be sure that this mark is facing your mouth.



"TALK" or a painted dot

#### SAFETY TIP

Attach the clothing clip to your shirt or to your seat belt on the chest area. Position it so that the controls are easy to find while driving.



*Continued on reverse side.*